OP-DB

ディスプレイ取付金具 対応一覧

| 搭載可能スタンド | ■ OP-DB481 | 2 OP-DB681 | 3 OP-DB441 | 4 OP-DB641 | 5 OP-DB341 |
|-----------------------|------------|------------|------------|------------|------------|
| MT-\$50 | 0 | 0 | × | × | × |
| MT-S100 | 0 | 0 | × | × | × |
| MI-4870 | 0 | 0 | × | × | × |
| XT-4055 | 0 | 0 | × | × | × |
| MH-2655 | 0 | 0 | × | × | × |
| HM-4055 | 0 | 0 | × | × | × |
| HS-4055 | 0 | 0 | × | × | × |
| MT-D30 | 0 | 0 | × | × | × |
| MT-DP30 | 0 | 0 | × | × | × |
| MT-M230 | 0 | 0 | × | × | × |
| PS-K55 | 0 | 0 | × | × | × |
| MT-W80 | 0 | 0 | × | × | × |
| MW-3755 | 0 | 0 | × | × | × |
| ST-75 | × | × | 0 | 0 | × |
| BT-55 | × | × | 0 | 0 | × |
| BT-32 | × | × | × | × | 0 |
| ML-3255 | 0 | 0 | × | × | × |
| OS-4055 | 0 | 0 | × | × | × |
| DS-S15B-A / DS-S15W-A | × | × | × | × | 0 |
| DS-S30B-A / DS-S30W-A | × | × | 0 | 0 | × |
| DS-S60B-A | × | × | 0 | 0 | × |
| DS-CS15 | × | × | 0 | × | 0 |
| DS-W45B / DS-W45W | × | × | 0 | 0 | × |
| DS-WS45 | × | × | 0 | 0 | × |
| DS-HW20B / DS-HW20W | × | × | 0 | 0 | × |
| OS-F45 | × | × | 0 | 0 | × |
| DS-R35 | 0 | \circ | × | × | × |
| WF02-400 | × | × | \circ | 0 | × |

注意事項

・スタンドに付属しているディスプレイ標準取付金具と排他取付になります。